

## 920-336 Other Nortel Certification

### Nortel 50 Rls.3.0 & BCM200/400 Rls.4.0 Installation, Config

**Practice Exam:** 920-336 Exams

**Exam Number/Code:** 920-336

**Exam Name:** 50 Rls.3.0 & BCM200/400 Rls.4.0 Installation, Config

**Questions and Answers:** 70 Q&As

( [Other Nortel Certification](#) )



Exam : [920-336](#)

"50 Rls.3.0 & BCM200/400 Rls.4.0 Installation, Config", also known as 920-336 exam, is a Nortel certification. With the complete collection of questions and answers, TestInside has assembled to take you through 70 Q&As to your 920-336 Exam preparation. In the 920-336 exam resources, you will cover every field and category in Nortel Certification helping to ready you for your successful Nortel Certification.

Quality and Value for the 920-336 Exam TestInside Practice Exams for Nortel **Other Nortel Certification** Certification 920-336 are written to the highest standards of technical accuracy, using only certified subject matter experts and published authors for development.

#### **TestInside provide the professional Q&A.**

1. We offer free update service for three month.

After you purchase our product, we will offer free update in time for three month.

2. High quality and Value for the 920-336 Exam.

920-336 simulation test questions, including the examination question and the answer, complete by our senior IT lecturers and the Other Nortel Certification product experts, included the current newest 920-336 examination questions.

3. 100% Guarantee to Pass Your Other Nortel Certification exam and get your Other Nortel Certification Certification. If you do not pass the Nortel Certification 920-336 exam (50 Rls.3.0 & BCM200/400 Rls.4.0 Installation, Config) on your first attempt using our TestInside testing engine and pdf file, we will give you a FULL REFUND of your purchasing fee.

#### **use TestInside 920-336 Q&A ensure you pass the exam at your first try.**

TestInside professional provide Other Nortel Certification 920-336 the newest Q&A, completely covers 920-336 test original topic. With our complete Other Nortel Certification resources, you will minimize your Other Nortel Certification cost and be ready to pass your 920-336 tests on Your First Try, 100% Money Back Guarantee included!

[Nortel 920-336](#) Test belongs to one of the Other Nortel Certification certified test, if needs to obtain the Other Nortel Certification certificate, you also need to participate in other related test, the details you may visit the [Other Nortel Certification](#) certified topic, in there, you will see all related Other Nortel Certification certified subject of examination.

#### **TestInside Testing Engine Features**

Comprehensive questions and answers about 920-336 exam

920-336 exam questions accompanied by exhibits

Verified Answers Researched by Industry Experts and almost 100% correct

920-336 exam questions updated on regular basis

Same type as the certification exams, 920-336 exam preparation is in multiple-choice questions (MCQs).

Tested by multiple times before publishing

Try free 920-336 exam demo before you decide to buy it in Test-Inside.com.

Note: This pdf demo do not include the question's picture.

Exam : Nortel 920-336

Title : BCM50 Rls.3.0 & BCM200/400 Rls.4.0 Installation, Config

1. The Nortel Business Communications Manager 50 (BCM50) expansion unit is designed to support Media Bay Modules (MBMs). These modules are available in many configurations. What is the maximum number of MBMs that the system can support?

- A. one
- B. two
- C. four
- D. six

Answer: B

2. You want to set up a guest mailbox for an out-of-town employee who is on temporary assignment at your location. How do you add the guest mailbox?

- A. Choose Subscriber as the mailbox type, enter the extension number.
- B. Choose Subscriber as the mailbox type, leave the extension number blank.
- C. Choose Guest as the mailbox type, leave the extension number blank.
- D. Choose Guest as the mailbox type, enter the extension number.

Answer: B

3. You are installing an IP 2004 telephone, and you require 24 extra line buttons on the telephone. Which piece of hardware do you require?

- A. Key Indicator Module (KIM)
- B. Key Expansion Module (KEM)
- C. Analog Terminal Adapter 2 (ATA2)
- D. Station Auxiliary Power Supply (SAPS)

Answer: B

4. You require a Nortel Business Communications Manager 50 (BCM50) system with an Ethernet router. Which main unit must you choose?

- A. BCM50
- B. BCM50a
- C. BCM50b
- D. BCM50e

Answer: D

5. On a Nortel Business Communications Manager 50 (BCM50) system, you want to prevent callers from being able to revert to the Attendant, in favor of Menu Repeat. Which digit do you select as the Menu Repeat Key?

- A. 0
- B. 1
- C. 8
- D. 9

Answer: A

6. Which three IP telephones are supported on the Nortel Business Communications Manager 50 (BCM50)? (Choose three.)

- A. IP Phone 1230
- B. IP Phone 1220
- C. IP Phone 2005
- D. IP Phone 1120e
- E. IP Phone 2008

Answer: ABD

7. You are using CallPilot Manager to restrict outdialing calls from a subscriber mailbox. Which action must you perform to do this?

- A. Set the Outdial Type for the subscriber mailbox to Line.
- B. Set the Outdial Type for the subscriber mailbox to Pool.
- C. Set the Outdial Type for the subscriber mailbox to None.
- D. Set the Outdial Type for the subscriber mailbox to Route.

Answer: C

8. You are installing a Nortel BCM50 at a small business site with seven digital stations. The customer wants to connect two PCs directly to the Nortel BCM50 to share the Internet connection. The Internet access is DSL. Which two hardware configurations can support this installation? (Choose two.)

- A. BCM50e main unit
- B. BCM50 main unit
- C. BCM expansion unit
- D. BCM50a main unit
- E. BCM50b main unit

Answer: AD

9. You require an additional four analog lines and an additional sixteen digital telephones connected to your Nortel Business Communications Manager 50 (BCM50). Which Media Bay Modules (MBMs) should you choose?

- A. G4x16
- B. CTM 4
- C. DSM 16+
- D. GASM 4x16

Answer: A

10. The system administrator is responsible for creating the subscriber mailboxes, but the owner must initialize the mailbox. Where are calls directed prior to the owner initialization?

- A. The calls are directed to the Guest Mailbox.
- B. The calls are queues in the Information Mailbox.
- C. The calls are directed to the General Delivery Mailbox.
- D. It is not possible to direct the call prior to the owner initializing the mailbox.

Answer: C

11. A customer has just opened a new office building for customer service and added 50 new employees. The telephone service has just been activated, and calls are now coming in. When someone calls and accesses the auto attendant, which feature can direct their calls?

- A. AMIS networking
- B. Mailbox Manager
- C. Dialing translation
- D. Company Directory

Answer: D

12. A customer wants to use the Message Networking optional feature of CallPilot. Which Class of Service setting

must be enabled for this optional feature to work?

- A. Enable Networking
- B. User Interface Style
- C. Enable Outbound Transfer
- D. Enable Personal Target Attendant

Answer: A

13. You are installing some IP 1200 Series Phones on a BCM50 and you require 18 extra line buttons on one of the telephones. Which hardware combination meets this requirement?

- A. Install an IP Phone 1210 and an 18-Key LED KIM.
- B. Install an IP Phone 1210 and an 18-Key LED KEM.
- C. Install an IP Phone 1220 and an 18-Key LED KIM.
- D. Install an IP Phone 1220 and an 18-Key LED KEM.

Answer: D

14. Which Digital Telephone supports the Key Indicator Module (KIM)?

- A. 7100
- B. 7208
- C. 7316E
- D. 7406E

Answer: C

15. On a Nortel Business Communications Manager 50 (BCM50), how do you program several special features at once for CallPilot mailboxes?

- A. Enable networking in the Class of Service.
- B. Assign features by selecting a Class of Service.
- C. Assign express messaging lines in mailbox properties.
- D. Purchase additional authorization codes.

Answer: B

### [More 920-336 Information](#)

#### **Related 920-336 Exams**

[922-109](#) *Communications Server 1000 RIs.6.0 BARS/NARS*

[922-101](#) *Communication Server 1000 Linux Platform Architecture*

[922-111](#) *Communication Server 1000 to RIs.6.0 Upgrades for Technicia*

[922-081](#) *CallPilot RIs.5.0 Networking*

[920-457](#) *CallPilot RIs.4.0 Unified Messaging Exam*

[922-104](#) *Communication Server 1000 RIs.6.0 Upgrades for Engineers*

[922-071](#) *BCM50 RIs.3.0 & BCM200/400 RIs.4.0 Config & Maintenance*

[920-110](#) *NNCSS SL-100 Maintenance Certification Exam*

[922-098](#) *Communication Server 1000 RIs.5.0 Troubleshooting*

[920-805](#) *Nortel Data Networking Technology*

[920-806](#) *Nortel Advanced Data Networking Technology*

[920-220](#) *Nortel Converged Campus ERS Solution*

[920-502](#) *nncss-optera metro 3000*

[920-569](#) *nncds-optera metro solutions*

[920-246](#) *Nortel WLAN 2300 RIs.5.0 Implementation & Management*

[920-520](#) *Nortel Agile Communication Environment (ACE) RIs. 1.x Design & Engineering*

922-099 *Communication Server 1000 RIs.5.0 Linux Platform Base & App*

922-094 *Communication Server 1000 RIs.5.0 Dialing Plan Design & IP*

920-197 *BCM50 RIs.2.0 & BCM200/400 RIs.4.0 Config & Maintenance*

920-199 *BCM50 Ris. 2.0 & BCM200/400 Ris. 4.0 ICM*

### **Other Nortel Exams**

920-129      920-123      920-115      920-433      920-571      920-464      920-355      920-533

920-316      922-108      920-140      922-079      922-104      920-322      920-469      920-803

920-544      920-215      920-163      920-240